

# Procedure To Cap Busted Hose

Identify The Hose With The Leak And Remove

Plug The Fitting With A  
3/8" Fitting And Pipe Tape



3/8" x 1" Threaded Pipe And Cap, Or Beveled Plug  
Note Swivel Fitting Has An Insert So Plug/Pipe Needs Bevel

